

SPECIFICATIONS	PF-61-025		
Flow Range	100-200 GPM		
System Inlet Connection	2 1/2" mpt		
System Outlet Connection	2 1/2" mpt		
Purge Connection	1" fpt		
Manual Air Bleed Valve	1/4" fpt		
Volume	7 GAL		
Est. Weight, Dry	77 lbs		
Est. Weight, Operating	130 lbs		

**ENGINEERING • MANUFACTURING • SERVICE** 

# PF-61-025 SPECIFICATION SHEET THREADED SEPARATOR

## Features:

- True tangential entry
- 150 psi working pressure
- Five year limited warranty
- Electrically actuated ball valve

## **Options:**

- Manual purge
- Isolation valve kit
- Wall mounting brackets/legs
- Inspection port

## SYSTEM COMPONENTS

### Separator :

- Carbon steel construction
- Fusion-bond polyester coated vessel
- Manual air bleed valve
- Inlet/Outlet pressure gauges

## **Electrical Controls :**


- NEMA 4X Enclosure
- Short circuit protection
- Purge switch selector
- Adjustable purge timer

PRESSURE DROP vs. FLOW RATE							
Pressure Drop	3 psi	4 psi	6 psi	8 psi	10 psi	12 psi	CV Factor
Flow (GPM)	99	114	139	161	180	197	56.9

\*(Flow rate / CV values may vary slightly

To determine the approximate pressure drop at flow rates not shown in this chart, use the following formula  $\Delta$ P= (FLOW RATE / CV)<sup>2</sup>

CV Factor: CV is defined as the flow in gallons per minute (GPM) that will produce a one pound pressure drop across the separator





3

2

WARNING !!!!!!

D

С


В

А

THE EMERGENCY "MAN" SWITCH AND EXTERNAL HAND WHEEL LOCATED ON THE PURGE ACTUATOR ARE ONLY TO BE USED WHEN THERE IS NO POWER TO THE ACTUATOR. DISCONNECT POWER TO THE CONTROL PANEL BEFORE USING THIS FEATURE OR DAMAGE MAY OCCUR TO THE ACTUATOR.

THIS FEATURE IS FOR EMERGENCIES ONLY!

IF VALVE DOES NOT OPEN OR CLOSE FULLY ADJUST ACTUATOR CAMS TO CORRECT THE PROBLEM.



REV

B REVISED TIMER

1 REVISIONS

DATE

5-24-16

DESCRIPTION

APPROVED

K.C.

#### TIMER SETTINGS

THE PUROFLUX AUTO PURGE TIMER IS EQUIPPED WITH CONTROL DIALS TO PROGRAM THE PURGING CYCLES TO MATCH YOUR SPECIFIC NEEDS.

\*\* POWER SHOULD BE TURNED OFF BEFORE CHANGING SETTINGS \*\*

OUT1 OUT2 PWR

RANGE 1S

T2

MODE

T1

RANGE 1H

15

15

30

30 SECONDS

6 HOURS

3

#### OPERATION MODE

MIDDLE DIAL (MODE) : TIMER OPERATION MODE FACTORY SETTING : "D"

#### CYCLE TIME

LOWER DIAL (T1) : FREQUENCY OF PURGING RANGE (1H) : 36 MINUTES TO 30 HOURS FACTORY SETTING : EVERY 6 HOURS

#### PURGING TIME

PURGING TIME

OPERATION MODE -

CYCLE TIME -

4

UPPER DIAL (T2) : DURATION OF PURGING RANGE (1S) : 0.6 TO 30 SECONDS FACTORY SETTING : 30 SECONDS